

Progressive®

Minimizes Hand Contact with Onions


Dice and Slice Chopper

At Progressive our goal is to make your busy life easier with innovative products for your kitchen. This Dice and Slice Chopper makes dicing and slicing produce for stir fries, salads and salsas quicker and easier.

Measures up to 2 Cups or 500 ml

Medium Dice, Small Dice and Slice Blades

Cleaning Tool



Features / Benefits

- Dices and Slices Produce in One Swift Motion
- Encloses Cut Foods to Minimize Mess
- Disassembles for Easy Cleaning

Cleaning

- Use cleaning tool to remove food residue from pusher teeth.
- Handwash lid for best results.
- All other parts are dishwasher safe.
- Nest pieces together in clean base for storage.

⚠ Caution!

- Sharp Blades. Use care when operating and washing item to avoid injury.


To Use



1. Remove blades from clear base container. Insert blade frame and press firmly into container rim.



4. Place food onto blades and push lid down firmly in one swift motion. Place both hands on lid when cutting larger pieces. Ease of chopping may vary depending on freshness and size of fruit or vegetable. **Tip:** Cut food down to 2" x 3" for best results.




2. Attach lid to base. Make sure lid is fully seated on hinge before pressing down.



5. Use cleaning tool to remove food residue from pusher teeth after each use. **Tip:** Keeping pusher teeth clean will prevent lifting of the chopping insert when opening the lid and will make chopping easier.



3. Lift tab on blade to remove or exchange blades. Snap desired blade into frame. **Medium Dice Suggested Uses:** Apples, Potatoes, Tomatoes. **Small Dice Suggested Uses:** Celery, Bell Peppers, Onions. **Slice Suggested Uses:** Mushrooms, Strawberries, Kiwi.



6. To remove blade frame from base container, hold base container down firmly with one hand. With other hand, lift frame up using finger hole.